



5. Childproof Lid

Using the screw provided fasten the lid to the water butt.



6. Tank-to-tank Connection

If you wish, you can connect two Novara Water Butts together using the drain down point near the base. A 250mm 3P 3/4" Tank to Tank Connection Kit is ideal for this.



Instructions

To fill the Novara, we recommend using the 3P Filter Collector Universal.

Where the water butt cannot be located within 30 cm of the downpipe, longer Long Link Kits are available from your dealer.



The 3P Filter Collector Universal is available in four colours to match your downpipe; black, grey, brown and white.

The Novara is delivered with an accessory kit which includes a chrome tap, wall bracket, and screws.

If in any doubt during installation, please consult a professional tradesperson or the supplier of your filter or diverter.



1. Setting up

Site the rain tank on a firm, level surface adjacent to a downpipe.

Read through these instructions and the 3P Filter Collector Instructions or other rain diverter instructions fully before proceeding.

If in any doubt during installation, please consult a professional tradesperson or the supplier of your filter or diverter.



2. Fitting the 3P Filter Collector Universal Link Kit

Locate the connection area

There are two connection areas - one on either side of the water butt. The Diverter Hose must be connected to either of these points. Drilling in other locations may result in leaks due to the surface design of the Novara.

Hole Cutter Selection - 32 mm

To fill the water butt with the recommended 3P Filter Collector Universal, select the 32 mm flat bit provided with the 3P Filter Collector Universal Kit.

Drilling

Offer the 32mm drill to your marked point, proceed to drill. If you are not fitting a 3P Filter Collector Universal, double check you are drilling the correct sized hole for your chosen connection set.



2. Continued

Attaching a Back-Nut & Hose Tail

Hold the back nut on the inside of the hole and screw on the hose tail and rubber grommet on the outside.



3. Connecting the Tap

Screw the 3/4" brass tap provided in the Kit into the 3/4" BSP connection thread. If necessary, use PTFE tape when installing the tap to create a more watertight seal and to allow the tap to sit in the correct position.

*** Top Tip!** Before filling with water, check the drain-down point is fully tightened. It may just need a 1/4 turn. A 2p or 50p piece is the perfect tool if you don't have the right sized screwdriver.

4. Fixing the Wall Bracket

Fill the tank with water * before attaching the wall bracket to avoid deflection. The bracket is optional.

Winter Care Precautions

During extremely cold winters, where daytime temperatures are below zero for several days, it is wise to ensure that the tank is only about 2/3rd's full and the water supply turned off. This will prevent the frozen water from expanding and damaging the tank.

