

The Prestige Wall Mounted Water Butt



The Prestige wall mounted water butt combines both a diverter and a reservoir in one unique product. Excess water overflows automatically and safely into the downpipe and on into your drain. When full and containing 100 ltrs (22 galls), natural expansion of the reservoir will occur. Both the reservoir and fixings have been designed to accommodate this. The higher the water butt is placed on the wall, the greater the 'head' of water pressure, thus enabling direct hosing of your plants. More than one butt can be connected together for increased storage capacity. A jointing kit is available.

Contents Checklist:

- 1 Wallmounted Water butt
- 2 L brackets
- 6 Screws and Plugs
- 1 Centre Button
- 1 Tap
- 1 Tap Bung *factory fitted*
- 2 Top caps *factory fitted*

Fixing Instructions

Follow these instructions carefully; all brackets and fixings must be used correctly. Use the correct sized drill bit and appropriate screwdriver head with the fixings provided.

Step 1 Decide Height

Decide the height and position at which you wish to fix the water butt, remembering to allow enough room for your watering can under the tap. The suggested height is 380mm (15"). At this point mark a level line on the wall.

Step 2 Bottom Pipe Clips

Any bottom pipe clip must be 125mm (5") below the water butt. Reposition if necessary.

Step 3 Outlet Section Cuts

Measure 1075mm (42 1/2") up from height line (A) and cut horizontally through the pipe. Now mark 140mm (5 1/2") above this cut and once again cut and remove this section (sections C).

Step 4 Top Pipe Clips

Ensure that any top clip is positioned at a minimum of 240mm (9 1/2") above the top of the reservoir for ease of fitting.

Step 5 Fixing Wall Brackets

Taking the metal wall brackets, sit level with line (A). The brackets must be separated horizontally by 220mm (9") to centres, symmetrical around the downpipe. The brackets will sit on the grooves on the underside of the water butt. Mark the holes, drill and fix the brackets to the wall with the screws-plugs provided.

Step 6 Fitting The Water Butt

Offer up the water butt to the top down pipe sliding it inside the centre hole of the butt until it will go no further. With the butt against the lower wall, lower it onto the bottom pipe section. Now with the butt seated level and evenly on the brackets, mark the position dead centre of the two top holes and **REMOVE THE WATER BUTT*** to allow for drilling. Drill two holes. Insert the plugs. Offer up the water butt. Screw in the screws. Do not overtighten.

***failure to do this may result in damage to the top area of the reservoir when using the drill.**

Finally fit the tap on the side you wish and the bung on the opposite side.

