



It is possible to connect two tanks together using the 3/4" BSP threads near the base of the water butt. Please use the 3P Connection Set 25 mm (Art. No. 9000326).



## Instructions

To fill the Norway, we recommend using the 3P Filter Collector (with rubber grommets for the 50mm push fit connection).

Where the downpipe is not immediately adjacent to the water butt please order a 3P Filter Collector with a 3P Long Link Kit (9000123L05). The latter requires use of the 50mm Grommet (that come with the Norway).

Where the water butt cannot be located within 50cm of the downpipe, the longer Long Kits are available online (Art. No. 9000123L to L5).



The Norway water butt is delivered with accessory kit including a brass tap, hole-saw, wall bracket, and screws. If in any doubt during installation, please consult a professional tradesman, or the supplier of your filter or diverter.





### 1. Setting Up

Site the Norway on a firm, level surface adjacent to a downpipe.

To allow for deflection, fill the tank with water before attaching the wall bracket.

Refer to your Filter Collector or diverter supplier's instructions. This is a sealed tank so you cannot use a backnut to make a connection through the tank wall.

### 2. Fitting a 3P Filter Collector with or without Link Kit, or Other Diverters & Connectors

For the correct hole size, refer to your diverter's instructions. You may be able to use the 3P hole saw set. Check before using. The connector parts supplied with the Norway are intended for use with the recommended 3P Filter Collector.

**For a 50mm push fit connection,** locate the area to form a hole for connecting the downpipe filter or diverter. You will need to drill a 58mm hole for a 50mm push fit onto the Filter Collector Push fit the 50mm grommet into that hole.

**To fill the water butt using a 3P Filter Collector with a 3P Long Link Kit (32mm hose),** select the 58mm hole saw from the set provided. Drill carefully a 58mm hole and then Push fit the 50mm grommet into that hole. Then push the 50mm plastic adapter bush (on the end of the link kit) into the grommet to make a water tight seal. It may need lubrication (soap) to ease the bush into the grommet.

**Drilling.** Offer the drill to the marked point and proceed to drill the hole.

**If you are fitting a brand of diverter other than 3P, check first that you are drilling the correct hole size for the diverter you are using.**

**IF IN ANY DOUBT CONSULT YOUR SUPPLIER OR A PROFESSIONAL**



### 3. Connecting the Tap

Screw the 3/4" metal tap provided into the 3/4" BSP connection thread.

If necessary, use PTFE tape when installing the tap to enhance the watertight seal and to ensure the tap sits in the correct VERTICAL position.

### 4. Base Threads & Winter Care Precautions

During extremely cold winters, where daytime temperatures are below zero for several days, it is wise to ensure that the tank is only about 2/3rd's full and the water supply turned off. This will prevent the frozen water from expanding and damaging the tank.

The 3/4" BSP threaded ports at the base can also be used to connect pumps or other tanks to the Norway \*.



**\* Top Tip!** Before filling with water, check the drain-down points are fully tightened. They may just need a 1/4 turn. A 2p or 50p piece is the perfect tool if you don't have the right sized screwdriver.