


5. Childproof lid

Using the screw provided, fasten the lid via the hole beneath the rim of the water butt.

6. Tank to Tank Connection

It is possible to connect two Helena Water Butts together.

Please use the 3P Tank to Tank connection Kit 250 mm (Art. no. 9000326).



Instructions




To fill the Helena, we recommend using the 3P Filter Collector Universal.

Where the water butt cannot be located within 30 cm of the downpipe, the longer Universal Long Link Kits are available online (Art. No. 9000123U to U5).

The Helena Water Butt is delivered with a kit including a $\frac{3}{4}$ " brass tap and optional wall bracket.

If in any doubt during installation, please consult a professional tradesperson.





1. Setting up

Site the Helena on a firm, level surface, adjacent to the downpipe.

Refer to your Filter Collector instructions or other rain diverter instructions. Connecting a tap is optional.

2. Fitting an (optional) 3P Filter Collector with Universal Link Kit. If you haven't purchased this Filter, follow the instructions for your diverter then go to step 3.

Marking Out

Measure down 90 mm from the lip of the water butt. This position is ideal for all connections at 32 mm (1 1/4") or less.



*** Top Tip!** Before filling with water, check the drain-down point is fully tightened. It may just need a 1/4 turn. A 2p or 50p piece is the perfect tool if you don't have the right sized screwdriver.

Hole Cutter Selection - 32 mm

To fill the water butt with the recommended 3P Universal Filter Collector, select the 32mm flat bit provided with the Filter Collector.

Drilling

Offer the drill to the marked point, proceed to drill the hole at 32 mm (or at your selected holes size for your connection set.) Check and re-check you are going to drill the correct size of hole for the connection set that you are using (especially if you are not fitting the 3P Filter Collector).

Attaching a Back-Nut & Hose Tail

A back nut and rubber seal can be fitted as shown. Hold the back nut and rubber seal in position and screw in the hose tail.

Hose tail in Position

This picture shows a 1" BSP thread - 32 mm hose tail in position (within a 32 mm drilled hole).

3. Connecting the Tap

With the 3/4" brass tap provided in the kit. Screw the tap into the 3/4" BSP connection thread. If necessary, use PTFE tape when installing the tap for extra protection and to make sure it sits in the correct position*.

4. Winter Care Precautions

During extremely cold winters, where daytime temperatures are below zero for several days, it is wise to ensure that the tank is only about 2/3rd's full and the water supply turned off. This will prevent the frozen water from expanding and damaging the tank.

**Filter Collector
Universal: Art. No:
2000840U**

